AXIS 700 and Visioneer Visual Explorer

Introduction

This document applies to the AXIS 700 Network Scan Server with software release 1.00 and subsequent releases until otherwise notified.

This document describes how to use your AXIS 700 together with Visioneer Visual Explorer (http://www.visioneer.com/). The document contains the following information:

- Setting up the AXIS 700 Network Scan Server for use with Visual Explorer
- Setting up Visual Explorer for use with AXIS 700 Network Scan Server
- Using Visual Explorer with AXIS 700 Network Scan Server

Any comments or suggestions regarding this document can be sent to products@axis.com.

Axis Communications AB (www.axis.com)

November 2nd, 1998

Table of Contents

Introduction 1
Required Environment 3
Setting up your AXIS 700 for Scan-to-File 3
Setting up Visual Explorer 4
Using Visual Explorer with AXIS 700 6

Required Environment

- An FTP server for scan-to-file which directories can be reached as a local or shared drive. The directories used as targets must exist and be available for reading and writing.
- Visioneer Visual Explorer 1.0 for Windows 95/98 installed.

Setting up your AXIS 700 for Scan-to-File

The method used is scan-to-file.

1. Specify a **Destination Name.** It is recommended to create a separate destination for each network user to enable a personal Visual Explorer folder.
2. Specify a default **Scanning Profile.** The **Text** profile (300 dpi black-n-white) should work with most documents. Any other of the pre-defined profiles as well as used defined PDF profiles can be used as the Visual Explorer support all AXIS 700 file formats (TIFF, JPG and PDF).
3. Set **Include Image Information** to **None**.
4. Specify the name/IP number of the FTP Server used in the **FTP Server** field.
5. Specify the **Directory** to be used on the FTP Server. This directory must exist.
6. The default settings can be used for the remaining fields.



Setting up Visual Explorer

1. Start Visual Explorer and select **File/Add to Folder View...**

2. For **Add to Folder View** select the folder where AXIS 700 stores the scanned images and Press OK. The Folder View will now include the new folder (a_smith on K:).



3. Visual Explorer will now automatically update the desktop when new items are put in the scanned folder (a_smith). Default time interval is 15 minutes. If faster automatic update of the desktop is wanted then select **Edit/Preferences** Select **SimpleSearch** and select wanted update time. Update can also be done manually with **F5** or **View/Refresh Thumbnails**.





Using Visual Explorer with AXIS 700

1. From the AXIS 700's control panel select the **Visual Explorer** destination and scan a document.

2. From Visual Explorer Folder View select the folder where the scanned images are stored. In this case, folder 'a_smith on K:'.

   Either wait for automatic update of the desktop or Press **F5**. Thumbnails will be created when idle according to the time set above or press **View/Update Thumbnails** for immediate update. The scanned image(s) can then be further processed on the Visual Explorer's desktop.